







3 KROKY

ke správnému vodítku...



MADE IN GERMANY

1. Jak aktivní a živý je váš pes?	2. Kolik váš pes váží?							
Klidný 	1 - 8 kg	9 - 15 kg	16 - 20 kg	21 - 25 kg	26 - 30 kg	31 - 40 kg	41 - 65 kg	65 kg +
Normálně aktivní 	1 - 7 kg	8 - 12 kg	13 - 15 kg	16 - 20 kg	21 - 25 kg	26 - 50 kg	51 - 60 kg	60 kg +
Živý 	1 - 4 kg	5 - 9 kg	10 - 12 kg	11 - 15 kg	16 - 18 kg	19 - 25 kg	26 - 35 kg	35 kg +
Velmi živý 		1 - 7 kg	8 - 10 kg		11-15 kg *	16 - 20 kg *	21 - 30 kg *	30 kg +*
3. Druh vodítka / doporučená minimální velikost								
Lanko 	XS →	S →	M →		L			
Pásek 		XS →	S →	M →		L →		XL

* Použijte prosím pouze vodítka s páskem.